



VI ZON ® with a double "Z" is a registered trademark of Sanyo Manufacturing Corporation.

FILE NO.

SERVICE MANUAL

Remote Control Plasma Color Television

DP42746 (U.S.A.) (CANADA) ORIGINAL VERSION



Chassis No. 42746-00

NOTE: Match the Chassis No. on the unit's back cover with the Chassis No. in the Service Manual.

> If the Original Version Service Manual Chassis No. does not match the unit's, additional Service Literature is required. You must refer to "Notices" to the Original Service Manual prior to servicing the unit.

Servicing should be performed by only trained and qualified service personnel.

Contents

C-4-4. . I.- -4... . -4...

Salety instructions
Service Adjustments 3 – 5
Power Failure Circuit 6
Mechanical Disassemblies 7 – 12
Chassis Electrical Parts List 13 – 20
Cabinet Parts List 21
Component and Test Point
Locations
Block Diagrams 25 – 28
Trouble Shooting Flow Charts 29 – 31
Control Port Functions32 – 33
Schematic Notes
Pin Layouts35
Capacitor and Resistor Codes36
Board Connections37 – 40
Schematic Diagrams 41 – 44

Specifications

Power Rating
351W, 4.2A (Max)
Antenna Input Impedance
UHF/VHF/CATV
Digital
Receiving Channel 2 - 13 (VHF),
14 - 69 (UHF),
01, 14-94, 95-125 (CATV)
1-99 (Digital)
Remote Ready 32 Key Remote Control
Sound Output 5.0 W/CH
Intermediate Frequency
Picture IF Carrier 45.75MHz
Sound IF Carrier 41.25MHz
Color Sub Carrier 42.17MHz
Cabinet Dimensions
Width 1206mm
Height
Depth including base 248mm

SAFETY INSTRUCTIONS

SAFETY PRECAUTIONS

WARNING: The chassis of this receiver has a floating ground with the potential of one half the AC line voltage in respect to earth ground. Service should not be attempted by anyone not familiar with the precautions necessary when working on this type of equipment.

The following precautions must be observed:

- An isolation transformer must be connected in the power line between the receiver and the AC line before any service is performed on the receiver.
- 2. Comply with all caution and safety-related notes provided inside the cabinet, on the chassis, and on the back.
- When replacing a chassis in the cabinet, always be certain that all the protective devices are installed properly, such as control knobs, adjustment covers, shields and barriers.
- Before replacing the back cover of the set, thoroughly inspect the inside of the cabinet to see that no stray parts or tools have been left inside.

Before returning any television to the customer, the service technician must perform the following safety checks to be sure that the unit is completely safe to operate without danger of electrical shock.

ANTENNA COLD CHECK

Remove AC plug from the 120 VAC outlet and place a jumper across the two blades. Connect one lead of an ohmmeter to the jumpered AC plug, and touch the other lead to each exposed antenna terminal (UHF and VHF antenna terminals). The resistance must measure between 1M ohm and 5.2M ohm. Any resistance value below or above this range indicates an abnormality which requires corrective action.

LEAKAGE CURRENT CHECK

Plug the AC line cord directly into a 120 VAC outlet. (Do not use an isolation transformer for this check.) Use an AC voltmeter, that has 5000 ohms per volt or more sensitivity. Connect a 1500 ohm 10 watt resistor, paralleled by a 0.15 μF 150 VAC capacitor, between a known good earth ground (water pipe, conduit, etc.) and all exposed metal parts of the cabinet (antennas, handle bracket, metal cabinet, screw heads, metal overlays, control shafts, etc.). Measure the AC voltage across the 1500 ohm resistor. The AC voltage should not exceed 750 mV. A reading exceeding 750 mV indicates that a dangerous potential exists. The fault must be located and corrected. Repeat the above test with the receiver power plug reversed.

NEVER RETURN A RECEIVER TO THE CUSTOMER WITHOUT TAKING THE NECESSARY CORRECTIVE ACTION.

PRODUCT SAFETY NOTICE


When replacing components in a receiver, always keep in mind the necessary product safety precautions. Pay special attention to the replacement of components marked with a star (\star) in the parts list and in the schematic diagrams. To ensure safe product operation, it is necessary to replace those components with the exact same PARTS.

READING SHOULD NOT EXCEED 750 mV.

AC VOLTMETER

(5000 ohms per volt or more sensitivity)

(5000 ohms per volt or more sensitivity)



Voltmeter Hook-up for Leakage Current Check.

SERVICING ELECTROSTATICALLY SENSATIVE DEVICES

Semiconductors (solid-state devices) that can be damaged by static electricity are referred to as Electrostatically Sensitive (ES) devices. Examples of typical ES devices are: Integrated Circuits (IC), Field-Effect Transistors (FET), and "chip" components. The following techniques should be observed strictly, to reduce the occurrence of semiconductor damage due to electrostatic discharge.

- Immediately prior to handling any semiconductor component or an assembly containing a semiconductor device or devices, discharge the electrostatic buildup on your body by touching a known earth ground. You may also obtain and wear a commercially available discharging wrist strap device.
 - CAUTION: Be sure to remove the wrist strap before applying power to any unit being serviced.
- 2. After removing an ES equipped assembly, place it on a conductive surface, such as, aluminum foil, to prevent buildup or exposure to static electricity.
- 3. Use only grounded-tip soldering irons to solder or unsolder ES devices.
- Use only anti-static solder removal devices. Some suction-type devices can generate static electricity adequate to damage ES devices.
- 5. A replacement ES device will come packaged in protective material (conductive foam, aluminum foil, or some comparable conductive material). Do Not remove an ES device from its protective packaging unless you are prepared to install it immediately.
- 6. Precisely prior to removing an ES device from its protective packaging, touch the protective packaging to the chassis or assembly in which the device will be installed.
 - CAUTION: Be sure that no power is applied to the chassis or circuit assembly.
- Incidental body movements, such as, lifting a foot from a carpeted floor or the rubbing of fabric together can generate static electricity sufficient to damage ES devices. Therefore, minimize all body movements while handling exposed (unpackaged) ES devices.

SERVICE ADJUSTMENTS

GENERAL

This set has an On-screen Service Menu system included in the CPU that allows remote operation for most of the service adjustments.

ON-SCREEN SERVICE MENU SYSTEM

1. Enter the Service Menu:

- Turn off the receiver and disconnect the AC power supply.
- While pressing the Volume (-) button on the television, reconnect the AC power supply. The Service
 Menu will now appear. The remote can now be used to make adjustments. See Figure 1 below.




Figure 1. Service Menu Display

2. Service Adjustments:


- Press the Channel ▲ or ▼ key to select the desired service menu item you want to adjust. See page 4 for the On-screen Service Menu.
- Use the **Volume** + or key or number keys to adjust the data.

The + or - keys will increase or decrease the data sequentially. The number keys (0 \sim 7) toggle only their respective bits between 1 and 0 and are used to change the Sub-Address. For example to change bit 5 press the number 5 key. See below.


Note: Using the + or – is not recommended due to possible rapid changes.


3. Exit from the Service Menu:

 Press the MENU key to turn off the Service Menu display.









ON-SCREEN SERVICE MENU

Table 1. ON-SCREEN SERVICE MENU

When IC802 (EEPROM) is replaced, check the bus data to confirm they are the same as below. The shaded menu should be checked and be set up or readjusted according to the procedures described in the following pages. Initial Setup Data marked with an * should be changed from Initial Reference Data. See page 3 for On-Screen Service Menu access and adjustments.

No.	TITLE	INITIAL REFERENCE DATA HEX	INITIAL SETUP DATA HEX	INITIAL SETUP DATA BINARY	FUNCTION
080	ATT	07	07	00000111	Attenuation -MTS Input Level (3~0)
081	SPC	20	20	00100000	Spectral - High Separation (5~3)
082	WDB	20	20	00100000	Wide Band - Low Separation (5~0)
083	SCO	00	00	00000000	Sub Color (NOT AVAILABLE)
084	STI	00	00	00000000	Sub Tint (NOT AVAILABLE)
085	SB	00	00	00000000	Sub Bright (NOT AVAILABLE)
086	SSH	00	00	00000000	Sub Sharpness (NOT AVAILABLE)
087	OP1	0A	0A	00001010	b7:PDP HD=0 b3:W/HDMI=1, PDP: b1,b0=10
088	OP2	00	00	00000000	b7:HD=0
08A	PER	00	00	00000000	Temperature Failure History (No Failure = 0, Failure = 1)
	PUT	0000	0000	00000000	Total Operation Time
1C0	\downarrow	\downarrow	\rightarrow	00000000	Not Used
1FF	\downarrow	\downarrow	\rightarrow	\downarrow	Not Used
200	1R01	00	00	00000000	ROM Correction Data
\downarrow	\downarrow	\	\	\	<u></u>
298	2R48↓	00	00	00000000	ROM Correcetion Data

- All data except in gray box area is fixed. Do not change for correct operation.
- Data in gray box is initial. Can be set according to adjustment information.

PROGRAM CODES

The microprossesor used in this model is a multi-purpose type and is used in several different models. To ensure proper operation and the correct features for your particular model, the program codes must be correct.

Note 1. Option Data 1 (NO. 087 OPT) should be hexadecimal 0A (00001010 binary). See 087 above. If this program code is wrong the TV will not operate properly.

Note 2. Option Data 2 (NO. 088 OP2) should be hexadecimal 00 (00000000 binary). See 088 above. If this program code is wrong the TV will not operate properly.

SERVICE ADJUSTMENTS (Continued)

MULTI-SOUND SECTION ADJUSTMENTS

Note: Multi-Sound Section must be adjusted after A101 (U/V Tuner), IC3401 (MTS Decoder), Digital Module or IC802 (EEPROM) is replaced.

INPUT LEVEL ADJUSTMENT

- 1. Connect a signal to the analog antenna terminal with audio of 1 KHz 100% modulation.
- Turn off the receiver and disconnect the AC power cord (AC 120V line).
- 3. Connect voltmeter (RMS) to TP317 and ground on the Main PC board.
- 4. While pressing the VOLUME key, reconnect the AC power cord. The Service Menu will now appear.
- Select NO. 080 (ATT: MTS Input Level) with the ▲ or ▼ key.
- Adjust the + or key for a voltmeter reading of 400 ± 20 mVrms at TP317.




Figure 2. Separation Adjustments

SEPARATION ADJUSTMENT

- 7. Turn off the receiver and disconnect the AC power cord (AC 120V line).
- 8. Connect oscilloscope CH1 to TP317 and CH2 to TP318 and ground.
- 9. Connect an MTS TV/Stereo generator to antenna terminal.
- 10. While pressing the VOLUME key, reconnect the AC power cord. The Service Menu will now appear.
- Select pilot, 300Hz audio frequency and Left modulating signal.
- 12. Select NO. 082 (WDB: Wide Band) with the ▲ or ▼ key.
- 13. Adjust the + or key for minimum low frequencies at TP317. See Figure 2.
- 14. Select 4 KHz audio frequency and Right modulating signal.
- 15. Select NO. 081 (SPC: Spectral) with the ▲ or ▼ key.
- 16. Adjust the + or key for minimum high frequencies at TP318. See Figure 2.

Repeat adjustments (steps 11–16) until no further decreases in amplitude can be obtained. Press the MENU key to turn off the Service Menu display.

POWER FAILURE CIRCUIT

CPU (IC801) is programmed so the set will go to the standby mode when there is circuit failure as described below. (Refer to "Power Supply Lines.")

1. Power Failure: Detected voltage failure. (Connected to IC801 pin 32.)

(Normal: High; Failure: Low)

2. Temperature Failure : Detected temperature failure for Power Unit of PDP module. (Connected to IC801 pin 41.)

(Normal: Low; Failure: High)

LED Flashing

When IC801 detects the Power Failure 3 times the LED will flash to indicate a power failure has occurred.

Note: The LED does not flash for Temperature Failures.

Note: If power failure is detected 3 times in 15 minutes, the set will enter the standby mode and cannot be switched On. To reset the operating programs of the CPU it is necessary to disconnect the AC cord for a short time.

History of Power Failure


When finishing the repair or stopping the Power Failure, the history of past failures can be checked.

To see the history

- 1. Enter the service mode. See "Service Adjustments" page 3.
- Select Item No. 08A PER Temperature Error.
 If Temperature Failure has accured the data in Item No. 08A will be 01h (1).

Attention:


After servicing, reset the data of Item No. 08A to 00h (0) with the Volume + or – key.



MECHANICAL DISASSEMBLY


BACK CABINET REMOVAL - SIDES

Remove 24 screws to take the side cabinets off. (A:3X8, 6pcs; B:4X12, 18pcs)




BACK CABINET REMOVAL- CENTER

Remove 31 screws to take the back cabinet off. (C:3X8, 10pcs; D:4X12, 17pcs; E:6X18, 4pcs)



MECHANICAL DISASSEMBLY (CONT.)

BOARD LOCATIONS



1: MAIN BOARD REMOVAL

Remove 2 tuner nuts (Digital and Analog) and take off the terminal base. Disconnect plugs K8MB, K8MA, K8A, K8B, K8F, K8E, and KSP. Remove 11 screws (3X8: 2 types) to take the main board with the shield case (assembly parts) off.

2: D-TU BOARD REMOVAL

Remove the terminal base. Disconnect plug K8LV. Remove 5 screws (3X8) to take the D-TU (digital) board with the shield case (assembly parts) off.

3: FILTER BOARD REMOVAL

Disconnect plug KAC. Remove 3 screws (3X8) to take the filter board with the shield case (assembly parts) off.

4: KEY SW BOARD REMOVAL

Disconnect plug K8E. Remove a screw (4X12) to take the key switch board with the panel, button, and holder (assembly parts) off.


5: CONTROL BOARD REMOVAL

The control board can be taken off, after the filter glass is removed. (Refer to 'FILTER GLASS REMOVAL'.)

6: SPEAKER REMOVAL


Disconnect plug KSP. Remove 4 screws (4X10) to take off each speaker.

SCREW LOCATIONS



STAND REMOVAL

Position TV face down on a padded or cushioned surface to protect the screen and finish. Remove 2 screws (6X18) from each foot and remove.




FILTER GLASS REMOVAL

- 1. Remove the key switch board.
- 2. Disconnect the following socket connections.

Control Board ~ Main Board: K8E Speakers ~ Main Board: KSP

3. Remove 8 screws (4X8) to take the panel module, power unit, and panel holders (Mounting Brackets) with boards off.


PLUG LOCATIONS



MECHANICAL DISASSEMBLY (CONT.)


FILTER GLASS REMOVAL (Cont.)


4. Remove 20 screws (G:3X8) to take the filter glass and upper plates off.



FRONT CABINET REMOVAL

- 1. Remove 18 screws (F:4X12) to take the filter glass with upper and lower plates (assembly parts) off.
- 2. Remove the speakers.
- 3. Remove a screw (4X10) to take the control board and holder off.





PANEL MODULE REMOVAL


- 1. Remove the key switch board.
- 2. Disconnect the following socket connections.

Main Board ~ Power Unit: CN8004, CN8007

D-TU Board ~ Power Unit: CN8010
Filter Board ~ Power Unit: CN8001
Control Board ~ Main Board: K8E
Speakers ~ Main Board: KSP
PDP Module ~ D TU Board K8LV

- 3. Remove the main board, D-TU board, and filter board.
- 4. Remove the 16 screws from the panel holders (Mounting Brackets) to take the panel module off.


(H:4X8, 14pcs; I:5X10, 2pcs)



MECHANICAL DISASSEMBLY (CONT.)

POWER UNIT REMOVAL

Remove 9 screws to take the power unit off.



ATTENTION

- This PDPTV uses several different kinds of screws. Using the **correct screw** is required to prevent damage.
- The **gasket** is provided to prevent interference to other radio and television receivers. The gasket must be returned to its previous position after servicing.
- Lead wires must be redressed to previous positions after servicing.

CHASSIS ELECTRICAL PARTS LIST

CAUTION: To Protect against electrical shock and for continued product safety, refer to SAFETY PRECAUTIONS, and PRODUCT SAFETY NOTICE on Page 2.

PRODUCT SAFETY NOTICE

PRODUCT SAFETY SHOULD BE CONSIDERED WHEN A REPLACEMENT IS MADE IN ANY AREA OF A RECEIVER. COMPONENTS INDICATED BY A STAR (*) IN THIS PARTS LIST AND THE SCHEMATIC DIAGRAM DESIGNATE COMPONENTS IN WHICH SAFETY CAN BE OF SPECIAL SIGNIFICANCE. IT IS PARTICULARLY RECOMMENDED THAT ONLY PARTS DESIGNATED ON THE FOLLOWING PARTS LIST BE USED FOR COMPONENT REPLACEMENT DESIGNATED BY A STAR. NO DEVIATIONS FROM RESISTANCE, WATTAGE, AND VOLTAGE RATINGS MAY BE MADE FOR REPLACEMENT ITEMS DESIGNATED BY A STAR.


Note: Schematic part location numbers may not always match with the part descriptions. The part descriptions are correct and should be used.

> TA-SOLID...... Tantalum Solid AL-SOLID..... Aluminium Solid ELECT..... Electrolytic

NP-ELECT...... Non-polarised Electrolytic OS-SOLID...... Aluminium Solid with Organic

Semiconductive Electrolytic

CAPACITORS



Schematic	Part No.	Description
Location	rait No.	Description

MAIN PC BOARD

	MAIN PC	: BOAI	RD		C1061	CEXLB1C101WAN	ELECT	100U M	16V
					C1062	CEXLB1C100WAN	ELECT	10U M	16V
					C1063	CEXLB1C100WAN	ELECT	10U M	16V
	CAPACITORS				C1064	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V
C002	CE1C470M4ZANN	ELECT	47U M	16V	C1065	CEXLB1C100WAN	ELECT	10U M	16V
C004	CK1H472KLZBNG	CERAMIC	4700P K	50V	C1066	CEXLB1H2R2WAN	ELECT	2.2U M	50V
C005	CE1E4R7M4ZANN	ELECT	4.7U M	25V	C1067	CEXLB1H2R2WAN	ELECT	2.2U M	50V
C007	CK1H472KLZBNG	CERAMIC	4700P K	50V	C1101	CEXLB1E4R7WAN	ELECT	4.7U M	25V
C008	CE1E4R7M4ZANN	ELECT	4.7U M	25V	C1102	CEXLB1E4R7WAN	ELECT	4.7U M	25V
C009	CE1E4R7M4ZANN	ELECT	4.7U M	25V	C1201	CEXLB1C101WAN	ELECT	100U M	16V
					C1202	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V
C012	CE1C102M4ZANN	ELECT	1000U M	16V	C1203	CEXLB1C100WAN	ELECT	10U M	16V
C013	CE1C102M4ZANN	ELECT	1000U M	16V	C1251	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V
C015	CEXLB1C101WAN	ELECT	100U M	16V	C1601	CK1E104ZLZFNG	CERAMIC	0.10 Z 0.1U Z	25V 25V
C016	CK1H103ZLZFNG	CERAMIC	0.01U Z	50V					
C017	CH1H103JAGANN	MT-COMPO	0.01U J	50V	C1602	CEXLB0J221WAN	ELECT	220U M	6.3V
C018	CH1H103JAGANN	MT-COMPO	0.01U J	50V	C1603	CEXLB1C221WAN	ELECT	220U M	16V
C019	CH1H103JAGANN	MT-COMPO	0.01U J	50V	C1604	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V
C020	CH1H103JAGANN	MT-COMPO	0.01U J	50V	C1605	CEXLB1C221WAN	ELECT	220U M	16V
C101	CK1H103ZLZFNG	CERAMIC	0.01U Z		C1606	CEXLB1H470WAN	ELECT	47U M	50V
C102	CK1H103ZLZFNG	CERAMIC	0.01U Z	50V	C1607	CEXLB1C221WAN	ELECT	220U M	16V
C105	CK1H103ZLZFNG	CERAMIC	0.01U Z	50V	C1608	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V
C106	CEXLB1H470WAN	ELECT	47U M	50V	C1612	CEXLB0J221WAN	ELECT	220U M	6.3V
C107	CEXLB0J102WAN	ELECT	1000U M	6.3V	C1613	CEXLB0J221WAN	ELECT	220U M	6.3V
C805	CC1H220JLZCNG	CERAMIC	22P J	50V	C1614	CEXLB0J221WAN	ELECT	220U M	6.3V
C806	CC1H220JLZCNG	CERAMIC	22P J	50V	C1616	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V
C807	CK1H103ZLZFNG	CERAMIC	0.01U Z	50V	C1617	CEXLB0J221WAN	ELECT	220U M	6.3V
C810	RGF5602JTCANL	MT-GLAZE	56K JA		C1618	CEXLB0J221WAN	ELECT	220U M	6.3V
C811	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V	C1619	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V
C813	CEXLB1A470WAN	ELECT	47U M	10V	C1620	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V
C814	CK1H222KLZBNG	CERAMIC	2200P K	50V	C1621	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V
C815	CC1H220JLZCNG	CERAMIC	22P J	50V	C1623	CK1H103ZLZFNG	CERAMIC	0.01U Z	50V
C816	CC1H22OJLZCNG	CERAMIC	22P J	50V	C1624	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V
					C1625	CK1E104ZLZFNG	CERAMIC	0.10 Z	25V
C820	CK1H103ZLZFNG	CERAMIC	0.01U Z	50V	C1801	CK1E104ZLZFNG	CERAMIC	0.10 Z	25V
C824	CK1H103ZLZFNG	CERAMIC	0.01U Z		C1851	CK1E104ZLZFNG	CERAMIC	0.10 Z	25V
C825	CC1H330JLZCNG	CERAMIC	33P J	50V					25V 25V
C826	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V	C1852	CK1E104ZLZFNG	CERAMIC	0.1U Z	
C827	CK1E104ZLZFNG	CERAMIC	0.1U Z		C1853	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V
C829	CK1E104ZLZFNG	CERAMIC	0.1U Z		C1854	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V
C834	CEXLB1C220WAN	ELECT	22U M	16V	C1855	CK1H103ZLZFNG	CERAMIC	0.01U Z	50V
C835	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V	C3401	CPXLB1H4R7ZAN		4.7U M	50V
C836	CC1H120JLZCNG	CERAMIC	12P J	50V	C3402	CEXLB1HR10WAN	ELECT	0.1U M	50V
C837	CC1H120JLZCNG	CERAMIC	12P J	50V	C3403	CPXLB1H4R7ZAN	NP-ELECT	4.7U M	50V
C838	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V	C3404	CK1H562KLZBNG	CERAMIC	5600P K	50V
C839	CK1H103ZLZFNG	CERAMIC	0.01U Z	50V	C3405	CK1H123KLZBNG	CERAMIC	0.012U K	50V
C840	CK1H333KLZBNG	CERAMIC	0.033U K	50V	C3406	CEXLB1H1R0WAN	ELECT	1U M	50V
C841	CEXLB1H2R2WAN	ELECT	2.2U M	50V	C3407	CEXLB1HR47WAN	ELECT	0.47U M	50V
C843	CC1H221JLZCNG	CERAMIC	220P J	50V	C3408	CEXLB1C470WAN	ELECT	47U M	16V
C1001	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V	C3409	CEXLB1E4R7WAN	ELECT	4.7U M	25V
C1002	CEXLB1C100WAN	ELECT	10U M	16V	C3410	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V
C1003	CEXLB1C100WAN	ELECT	10U M	16V	C3411	CPXLB1H4R7ZAN	NP-ELECT	4.7U M	50V
C1004	CEXLB1H2R2WAN	ELECT	2.2U M	50V	C3412	CEXLB1E4R7WAN	ELECT	4.7U M	25V
C1005	CEXLB1H2R2WAN	ELECT	2.2U M	50V	C3413	CEXLB1C471WAN	ELECT	470U M	16V
C1003	CEXLB1C101WAN	ELECT	100U M	16V	C3414	CPXLB1H4R7ZAN	NP-ELECT	4.7U M	50V
C1021	CEXLB1C101WAN	ELECT	1000 M	16V	C3415	CK1H272KLZBNG	CERAMIC	2700P K	50V
C1022	CEXLB1C100WAN	ELECT	100 M	16V	C3416	CK1H473KLZBNG	CERAMIC	0.047U K	50V
					C3417	CT1A3R3KDRANG	TA-SOLID	3.3U K	10V
C1024	CK1E104ZLZFNG	CERAMIC	0.1U Z	25V	C3417	CPXLB1H4R7ZAN	NP-ELECT	4.7U M	50V
C1025	CEXLB1C100WAN	ELECT	10U M	16V					
C1026	CEXLB1H2R2WAN	ELECT	2.2U M	50V	C3419	CT1A100KDRANG	TA-SOLID	10U K	10V
C1027	CEXLB1H2R2WAN	ELECT	2.2U M	50V					

Schematic

Location

C1061

Part No.

CEXLB1C101WAN

Description

100U M

16V

ELECT

Schematic Location	Part No.	Description			Schematic Location	Part No.	Description
C3420	CEXLB1H1R0WAN	ELECT 1U N	/I 50V	•	L805	1AV4L26B0130G	INDUCTOR, 600 OHM
C3421	CEXLB1H1R0WAN		/I 50V		L806	1AV4L26B0130G	INDUCTOR, 600 OHM
C3422	CEXLB1H1R0WAN				L1021	1AV4L2FB3R3MG	INDUCTOR, 3.3U M
C3423	CEXLB1H1R0WAN				L1201	1AV4L2FB3R3MG	INDUCTOR, 3.3U M
C3424	CEXLB1H1R0WAN				L1601	1AV4L26B2770G	INDUCTOR, 220 OHM
C3425	CK1H223KLZBNG	CERAMIC 0.022U			L1602	1AV4L26B2770G	INDUCTOR, 220 OHM
C3426	CK1H472KLZBNG	CERAMIC 4700P			L1605	1AV4L26B0130G	INDUCTOR, 600 OHM
C3427	CPXLB1H4R7ZAN	NP-ELECT 4.7U N			L1609	1AV4L26B2770G	INDUCTOR, 220 OHM
C3428	CEXLB1HR10WAN	ELECT 0.1U N			L1610	1AV4L26B2770G	INDUCTOR, 220 OHM
C3429	CK1H472KLZBNG	CERAMIC 4700P			L1611	1AV4L26B2770G	INDUCTOR, 220 OHM
C3430	CEXLB1C471WAN	ELECT 470U N			L1612	1AV4L26B2770G	INDUCTOR, 220 OHM
					L1615	1AV4L26B2770G	INDUCTOR, 220 OHM
					L1616	1AV4L26B2770G	INDUCTOR, 220 OHM
	DIODES				L1617	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
D001	DDRB551V-30-G	DIODE RB551V-30 TE-	17		L1618	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
D801	DD1SS355G	DIODE 1SS355 TE-17			L1619	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
D802	DZUDZS6.2BG	ZENER DIODE UDZS6.	2R TF-17		L1620	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
D803	DD1SS355G	DIODE 1SS355 TE-17	LD 1L 17		L1801	1AV4L26B0130G	INDUCTOR, 600 OHM
D1601	DD1SS355G	DIODE 1SS355 TE-17			L1803	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
D1602	DD1SS355G	DIODE 1SS355 TE-17			L1804	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
D1603	DD1SS355G	DIODE 188355 TE-17			L1805	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
D1604	DD1SS355G	DIODE 188355 TE-17			L1806	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
D1605	DD1SS355G	DIODE 188355 TE-17			L1807	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
D1606	DD1SS355G	DIODE 1SS355 TE-17			L1808	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
D1607	DZUDZS3.0BG	ZD UDZS3.0B-TE-17			L1809	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
D1801	DZUDZS10BG	ZENER DIODE UDZS10	B TF-17		L1810	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
D3401	DDRB551V-30-G	DIODE RB551V-30 TE-			L1815	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
D0401	DDIIDOOTV OO G	DIODE NOOTV OO TE	.,		L1885	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
					L1891	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
	INTEGRATED	CIRCUITS			L1893	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
IC001	QLA42072N-E-N	IC LA42072N-E			L1894	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
IC801	QXXAAJQ0730	IC LC87F4164AU-PDP	001		L1895	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
10001	QXXAVC779M	IC LC874164A-57XX-E			L1896	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
IC802	Q24LC08BT/SNP	IC 24LC08BT/SN			L3401	1AV4L2FB3R3MG	INDUCTOR, 3.3U M
IC803	QMN1381-QN	IC MN1381-Q					
IC805	QTC7SH08FUP	IC TC7SH08FU					
IC806	QTC7SET08FP	IC TC7SET08F-TE85L				TRANSISTOR	RS
IC1201	QCD4052BNSR-P	IC CD4052BNSR			Q101	T2SC2412K-R-P	TR 2SC2412K-T-96-R
101201	QTC4052BFP	IC TC4052BF-EL				T2SC2412K-S-P	TR 2SC2412K-T-96-S
IC1251	QCD4052BNSR-P	IC CD4052BNSR				T2SC2812-L6-P	TR 2SC2812-L6-TB
101201	QTC4052BFP	IC TC4052BF-EL				T2SC2812-L7-P	TR 2SC2812-L7-TB
IC1601	QBA90BC0WFP-P	IC BA90BC0WFP-E2				T2SC2812N-L6P	TR 2SC2812N-L6-TB
IC1604	QXXAVC550G	IC PQ018EZ02ZPH				T2SC2812N-L7P	TR 2SC2812N-L7-TB
IC3401	QCXA2234QP	IC CXA2234Q-T6				T2SC3928A1R-P	TR 2SC3928A1R
						T2SC3928A1S-P	TR 2SC3928A1S
					Q102	T2SC2412K-R-P	TR 2SC2412K-T-96-R
	COILS					T2SC2412K-S-P	TR 2SC2412K-T-96-S
L001	1AV4L26B2770G	INDUCTOR, 220 OHM				T2SC2812-L6-P	TR 2SC2812-L6-TB
L002	1AV4L26B2770G	INDUCTOR, 220 OHM				T2SC2812-L7-P	TR 2SC2812-L7-TB
L004	1AV4L26B2770G	INDUCTOR, 220 OHM				T2SC2812N-L6P	TR 2SC2812N-L6-TB
L005	1AV4L26B2770G	INDUCTOR, 220 OHM				T2SC2812N-L7P	TR 2SC2812N-L7-TB
L101	1AV4L2FB3R3MG	INDUCTOR, 3.3U M				T2SC3928A1R-P	TR 2SC3928A1R
L102	1AV4L2FB3R3MG	INDUCTOR, 3.3U M				T2SC3928A1S-P	TR 2SC3928A1S
L103	RGFR000ZTCANL		4 1/10W		Q801	T2SC2412K-R-P	TR 2SC2412K-T-96-R
L106	RGFR000ZTCANL		4 1/10W			T2SC2412K-S-P	TR 2SC2412K-T-96-S
L107	RGFR000ZTCANL		4 1/10W			T2SC2812-L6-P	TR 2SC2812-L6-TB
L801	1AV4L2FB3R3MG	INDUCTOR, 3.3U M				T2SC2812-L7-P	TR 2SC2812-L7-TB
L802	1AV4L26B2770G	INDUCTOR, 220 OHM				T2SC2812N-L6P	TR 2SC2812N-L6-TB

Schematic Location	Part No.	Description		Schematic Location	Part No.	Description
	T2SC2812N-L7P	TR 2SC2812N-L7-TB	,		T2SA1037K-S-P	TR 2SA1037K-T-96-S
	T2SC3928A1R-P	TR 2SC3928A1R			T2SA1179-M6-P	TR 2SA1179-M6
	T2SC3928A1S-P	TR 2SC3928A1S			T2SA1179-M7-P	TR 2SA1179-M7-TB
Q803	T2SC2412K-R-P	TR 2SC2412K-T-96-R			T2SA1179N-M6P	TR 2SA1179N-M6-TB
	T2SC2412K-S-P	TR 2SC2412K-T-96-S			T2SA1179N-M7P	TR 2SA1179N-M7-TB
	T2SC2812-L6-P	TR 2SC2812-L6-TB			T2SA1235A1E-P	TR 2SA1235A1E
	T2SC2812-L7-P	TR 2SC2812-L7-TB			T2SA1235A1F-P	TR 2SA1235A1F
	T2SC2812N-L6P	TR 2SC2812N-L6-TB		Q1023	T2SA1037AK-RP	TR 2SA1037AK T146 R
	T2SC2812N-L7P	TR 2SC2812N-L7-TB			T2SA1037AK-SP	TR 2SA1037AK T146 S
	T2SC3928A1R-P	TR 2SC3928A1R			T2SA1037K-R-P	TR 2SA1037K-T-96-R
	T2SC3928A1S-P	TR 2SC3928A1S			T2SA1037K-S-P	TR 2SA1037K-T-96-S
Q804	T2SA1037AK-RP	TR 2SA1037AK T146 R			T2SA1179-M6-P	TR 2SA1179-M6
	T2SA1037AK-SP	TR 2SA1037AK T146 S			T2SA1179-M7-P	TR 2SA1179-M7-TB
	T2SA1037K-R-P	TR 2SA1037K-T-96-R			T2SA1179N-M6P	TR 2SA1179N-M6-TB
	T2SA1037K-S-P	TR 2SA1037K-T-96-S			T2SA1179N-M7P	TR 2SA1179N-M7-TB
	T2SA1179-M6-P	TR 2SA1179-M6			T2SA1235A1E-P	TR 2SA1235A1E
	T2SA1179-M7-P	TR 2SA1179-M7-TB			T2SA1235A1F-P	TR 2SA1235A1F
	T2SA1179N-M6P	TR 2SA1179N-M6-TB		Q1061	T2SA1037AK-RP	TR 2SA1037AK T146 R
	T2SA1179N-M7P	TR 2SA1179N-M7-TB			T2SA1037AK-SP	TR 2SA1037AK T146 S
	T2SA1235A1E-P	TR 2SA1235A1E			T2SA1037K-R-P	TR 2SA1037K-T-96-R
	T2SA1235A1F-P	TR 2SA1235A1F			T2SA1037K-S-P	TR 2SA1037K-T-96-S
Q805	T2SC2412K-R-P	TR 2SC2412K-T-96-R			T2SA1179-M6-P	TR 2SA1179-M6
	T2SC2412K-S-P	TR 2SC2412K-T-96-S			T2SA1179-M7-P	TR 2SA1179-M7-TB
	T2SC2812-L6-P	TR 2SC2812-L6-TB			T2SA1179N-M6P	TR 2SA1179N-M6-TB
	T2SC2812-L7-P	TR 2SC2812-L7-TB			T2SA1179N-M7P	TR 2SA1179N-M7-TB
	T2SC2812N-L6P	TR 2SC2812N-L6-TB			T2SA1235A1E-P	TR 2SA1235A1E
	T2SC2812N-L7P	TR 2SC2812N-L7-TB		01000	T2SA1235A1F-P	TR 2SA1235A1F
	T2SC3928A1R-P	TR 2SC3928A1R		Q1062	T2SA1037AK-RP	TR 2SA1037AK T146 R
0001	T2SC3928A1S-P	TR 2SC3928A1S			T2SA1037AK-SP	TR 2SA1037AK T146 S
Q901	T2SC2412K-R-P T2SC2412K-S-P	TR 2SC2412K-T-96-R TR 2SC2412K-T-96-S			T2SA1037K-R-P T2SA1037K-S-P	TR 2SA1037K-T-96-R TR 2SA1037K-T-96-S
	T2SC2812-L6-P	TR 2SC2812-L6-TB			T2SA1037K-3-P	TR 2SA1179-M6
	T2SC2812-L0-P	TR 2SC2812-L7-TB			T2SA1179-M0-P	TR 2SA1179-M0
	T2SC2812N-L6P	TR 2SC2812N-L6-TB			T2SA1179-M7-F	TR 2SA1179-W7-TB
	T2SC2812N-L7P	TR 2SC2812N-L7-TB			T2SA1179N-M7P	TR 2SA1179N-M7-TB
	T2SC3928A1R-P	TR 2SC3928A1R			T2SA1235A1E-P	TR 2SA1235A1E
	T2SC3928A1S-P	TR 2SC3928A1S			T2SA1235A1F-P	TR 2SA1235A1F
Q902	T2SC2412K-R-P	TR 2SC2412K-T-96-R		Q1063	T2SA1037AK-RP	TR 2SA1037AK T146 R
4002	T2SC2412K-S-P	TR 2SC2412K-T-96-S		4.000	T2SA1037AK-SP	TR 2SA1037AK T146 S
	T2SC2812-L6-P	TR 2SC2812-L6-TB			T2SA1037K-R-P	TR 2SA1037K-T-96-R
	T2SC2812-L7-P	TR 2SC2812-L7-TB			T2SA1037K-S-P	TR 2SA1037K-T-96-S
	T2SC2812N-L6P	TR 2SC2812N-L6-TB			T2SA1179-M6-P	TR 2SA1179-M6
	T2SC2812N-L7P	TR 2SC2812N-L7-TB			T2SA1179-M7-P	TR 2SA1179-M7-TB
	T2SC3928A1R-P	TR 2SC3928A1R			T2SA1179N-M6P	TR 2SA1179N-M6-TB
	T2SC3928A1S-P	TR 2SC3928A1S			T2SA1179N-M7P	TR 2SA1179N-M7-TB
Q1021	T2SA1037AK-RP	TR 2SA1037AK T146 R			T2SA1235A1E-P	TR 2SA1235A1E
	T2SA1037AK-SP	TR 2SA1037AK T146 S			T2SA1235A1F-P	TR 2SA1235A1F
	T2SA1037K-R-P	TR 2SA1037K-T-96-R		Q1101	T2SC2412K-R-P	TR 2SC2412K-T-96-R
	T2SA1037K-S-P	TR 2SA1037K-T-96-S			T2SC2412K-S-P	TR 2SC2412K-T-96-S
	T2SA1179-M6-P	TR 2SA1179-M6			T2SC2812-L6-P	TR 2SC2812-L6-TB
	T2SA1179-M7-P	TR 2SA1179-M7-TB			T2SC2812-L7-P	TR 2SC2812-L7-TB
	T2SA1179N-M6P	TR 2SA1179N-M6-TB			T2SC2812N-L6P	TR 2SC2812N-L6-TB
	T2SA1179N-M7P	TR 2SA1179N-M7-TB			T2SC2812N-L7P	TR 2SC2812N-L7-TB
	T2SA1235A1E-P	TR 2SA1235A1E			T2SC3928A1R-P	TR 2SC3928A1R
	T2SA1235A1F-P	TR 2SA1235A1F			T2SC3928A1S-P	TR 2SC3928A1S
Q1022	T2SA1037AK-RP	TR 2SA1037AK T146 R				
	T2SA1037AK-SP	TR 2SA1037AK T146 S				
	T2SA1037K-R-P	TR 2SA1037K-T-96-R				

Schematic Location	Part No.	Description	Schematic Location	Part No.	Description
Q1102	T2SC2412K-R-P	TR 2SC2412K-T-96-R	Q3404	T2SC2412K-R-P	TR 2SC2412K-T-96-R
	T2SC2412K-S-P	TR 2SC2412K-T-96-S		T2SC2412K-S-P	TR 2SC2412K-T-96-S
	T2SC2812-L6-P	TR 2SC2812-L6-TB		T2SC2812-L6-P	TR 2SC2812-L6-TB
	T2SC2812-L7-P	TR 2SC2812-L7-TB		T2SC2812-L7-P	TR 2SC2812-L7-TB
	T2SC2812N-L6P	TR 2SC2812N-L6-TB		T2SC2812N-L6P	TR 2SC2812N-L6-TB
	T2SC2812N-L7P	TR 2SC2812N-L7-TB		T2SC2812N-L7P	TR 2SC2812N-L7-TB
	T2SC3928A1R-P	TR 2SC3928A1R		T2SC3928A1R-P	TR 2SC3928A1R
01001	T2SC3928A1S-P	TR 2SC3928A1S TR 2SC2412K-T-96-R	00405	T2SC3928A1S-P	TR 2SC3928A1S
Q1201	T2SC2412K-R-P T2SC2412K-S-P	TR 2SC2412K-T-96-R TR 2SC2412K-T-96-S	Q3405	T2SC2412K-R-P T2SC2412K-S-P	TR 2SC2412K-T-96-R TR 2SC2412K-T-96-S
	T2SC2812-L6-P	TR 2SC2812-L6-TB		T2SC2812-L6-P	TR 2SC2812-L6-TB
	T2SC2812-L0-P	TR 2SC2812-L7-TB		T2SC2812-L7-P	TR 2SC2812-L7-TB
	T2SC2812N-L6P	TR 2SC2812N-L6-TB		T2SC2812N-L6P	TR 2SC2812N-L6-TB
	T2SC2812N-L7P	TR 2SC2812N-L7-TB		T2SC2812N-L7P	TR 2SC2812N-L7-TB
	T2SC3928A1R-P	TR 2SC3928A1R		T2SC3928A1R-P	TR 2SC3928A1R
	T2SC3928A1S-P	TR 2SC3928A1S		T2SC3928A1S-P	TR 2SC3928A1S
Q1202	T2SC2412K-R-P	TR 2SC2412K-T-96-R			
	T2SC2412K-S-P	TR 2SC2412K-T-96-S			
	T2SC2812-L6-P	TR 2SC2812-L6-TB		RESISTORS	
	T2SC2812-L7-P	TR 2SC2812-L7-TB	★ R001	RG11R00JTEANL	MT-GLAZE 1 JA 1W
	T2SC2812N-L6P	TR 2SC2812N-L6-TB	★ R002	RG11R00JTEANL	MT-GLAZE 1 JA 1W
	T2SC2812N-L7P	TR 2SC2812N-L7-TB	R003	RGF4701JTCANL	MT-GLAZE 4.7K JA 1/10W
	T2SC3928A1R-P	TR 2SC3928A1R	R004	RGF6801JTCANL	MT-GLAZE 6.8K JA 1/10W
Q1203	T2SC3928A1S-P T2SC2412K-R-P	TR 2SC3928A1S TR 2SC2412K-T-96-R	R005	RGF4701JTCANL	MT-GLAZE 4.7K JA 1/10W
Q1203	T2SC2412K-R-P	TR 2SC2412K-T-96-S	R006 ★ R007	RGF6801JTCANL	MT-GLAZE 6.8K JA 1/10W
	T2SC2812-L6-P	TR 2SC2812-L6-TB	₩ R007 R012	RG11R00JTEANL RGA2R20JTDANL	MT-GLAZE 1 JA 1W MT-GLAZE 2.2 JA 1/2W
	T2SC2812-L0-P	TR 2SC2812-L0-TB	R013	RGA2R20JTDANL	MT-GLAZE 2.2 JA 1/2W
	T2SC2812N-L6P	TR 2SC2812N-L6-TB	R014	RGA2R20JTDANL	MT-GLAZE 2.2 JA 1/2W
	T2SC2812N-L7P	TR 2SC2812N-L7-TB	R015	RGA2R20JTDANL	MT-GLAZE 2.2 JA 1/2W
	T2SC3928A1R-P	TR 2SC3928A1R	R016	RGF5601JTCANL	MT-GLAZE 5.6K JA 1/10W
	T2SC3928A1S-P	TR 2SC3928A1S	R101	RGF1000JTCANL	MT-GLAZE 100 JA 1/10W
Q1251	T2SC2412K-R-P	TR 2SC2412K-T-96-R	R102	RGF1000JTCANL	MT-GLAZE 100 JA 1/10W
	T2SC2412K-S-P	TR 2SC2412K-T-96-S	R103	RGF1000JTCANL	MT-GLAZE 100 JA 1/10W
	T2SC2812-L6-P	TR 2SC2812-L6-TB	R104	RGF1000JTCANL	MT-GLAZE 100 JA 1/10W
	T2SC2812-L7-P	TR 2SC2812-L7-TB	R105	RGF56R0JTCANL	MT-GLAZE 56 JA 1/10W
	T2SC2812N-L6P	TR 2SC2812N-L6-TB	R109	RGF4700JTCANL	MT-GLAZE 470 JA 1/10W
	T2SC2812N-L7P T2SC3928A1R-P	TR 2SC2812N-L7-TB TR 2SC3928A1R	R110	RGFR000ZTCANL	MT-GLAZE 0.000 ZA 1/10W
	T2SC3928A1S-P	TR 2SC3928A1S	R111	RGF33R0JTCANL	MT-GLAZE 33 JA 1/10W MT-GLAZE 0.000 ZA 1/10W
Q1252	T2SC2412K-R-P	TR 2SC2412K-T-96-R	R112 R801	RGFR000ZTCANL RGF4701JTCANL	MT-GLAZE 0.000 ZA 1/10W MT-GLAZE 4.7K JA 1/10W
Q 1202	T2SC2412K-S-P	TR 2SC2412K-T-96-S	R803	RGF1000JTCANL	MT-GLAZE 4.7K 3A 1/10W
	T2SC2812-L6-P	TR 2SC2812-L6-TB	R806	RGF2202JTCANL	MT-GLAZE 22K JA 1/10W
	T2SC2812-L7-P	TR 2SC2812-L7-TB	R807	RGF1000JTCANL	MT-GLAZE 100 JA 1/10W
	T2SC2812N-L6P	TR 2SC2812N-L6-TB	R809	RGF4701JTCANL	MT-GLAZE 4.7K JA 1/10W
	T2SC2812N-L7P	TR 2SC2812N-L7-TB	R812	RGF1000JTCANL	MT-GLAZE 100 JA 1/10W
	T2SC3928A1R-P	TR 2SC3928A1R	R815	RGF1000JTCANL	MT-GLAZE 100 JA 1/10W
	T2SC3928A1S-P	TR 2SC3928A1S	R816	RGF1000JTCANL	MT-GLAZE 100 JA 1/10W
Q1801	T2SC2412K-R-P	TR 2SC2412K-T-96-R	R818	RGF1000JTCANL	MT-GLAZE 100 JA 1/10W
	T2SC2412K-S-P	TR 2SC2412K-T-96-S	R822	RGF4701JTCANL	MT-GLAZE 4.7K JA 1/10W
	T2SC2812-L6-P	TR 2SC2812-L6-TB	R823	RGF1000JTCANL	MT-GLAZE 100 JA 1/10W
	T2SC2812-L7-P T2SC2812N-L6P	TR 2SC2812-L7-TB TR 2SC2812N-L6-TB	R824	RGF1002JTCANL	MT-GLAZE 10K JA 1/10W
	T2SC2812N-L7P	TR 2SC2812N-L7-TB	R825 R828	RGF2201JTCANL RGF4701JTCANL	MT-GLAZE 2.2K JA 1/10W MT-GLAZE 4.7K JA 1/10W
	T2SC3928A1R-P	TR 2SC3928A1R	R829	RGF4701JTCANL	MT-GLAZE 4.7K JA 1/10W
	T2SC3928A1S-P	TR 2SC3928A1S	R830	RGF1002JTCANL	MT-GLAZE 4.7K JA 1/10W
		-	R831	RGF4702JTCANL	MT-GLAZE 47K JA 1/10W
			R832	RGF4702JTCANL	MT-GLAZE 47K JA 1/10W

R833 R6F2701JTCANIL MT-GLAZE 2.7% JA 1/10W R1003 R6F2760JTCANIL MT-GLAZE 476 JA 1/10W R108 R6F270JTCANIL MT-GLAZE 220 JA 1/10W R108 R6F270JTCANIL MT-GLAZE 220 JA 1/10W R109 R6F100JTCANIL MT-GLAZE 100 JA 1/10W R1010 R6F100JTCANIL MT-GLAZE 100 JA 1/10W R1010 R6F100JTCANIL MT-GLAZE 100 JA 1/10W R1021 R6F75RGJTCANIL MT-GLAZE 100 JA 1/10W R1021 R6F75RGJTCANIL MT-GLAZE 75 JA 1/10W R1021 R6F75RGJTCANIL MT-GLAZE 75 JA 1/10W R1021 R6F75RGJTCANIL MT-GLAZE 75 JA 1/10W R1023 R6F75RGJTCANIL MT-GLAZE 75 JA 1/10W R1033 R6F75RGJTCANIL MT-GLAZE 47 JA 1/10W R1034 R6F75RGJTCANIL MT-GLAZE 47 JA 1/10W R1034 R6F75RGJTCANIL MT-GLAZE 47 JA 1/10W R1035 R6F75RGJTCANIL MT-GLAZE 47 JA 1/10W R1034 R6F75RGJTCANIL MT-GLAZE 47 JA 1/10W R1035 R6F75RGJTCANIL MT-GLAZE 47 JA 1/10W R1036 R6F75RGJTCANIL MT-GLAZE 47 JA 1/10W R1036 R6F75RGJTCANIL MT-GLAZE 47 JA 1/10W R1036	Schematic Location	Part No.	Des	scription	Schematic Location	Part No.	De	scription
R839	R833	RGF2701JTCANL	MT-GLAZE	2.7K JA 1/10W	R1003	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W
R839 R6F10001TCANL MT-GLAZE 100 JA 1/10W R1007 R6F2200LTCANL MT-GLAZE 220 JA 1/10W R841 R6F10001TCANL MT-GLAZE 100 JA 1/10W R1009 R6F2200LTCANL MT-GLAZE 220 JA 1/10W R843 RGF10001TCANL MT-GLAZE 100 JA 1/10W R1009 R6F2200LTCANL MT-GLAZE 220 JA 1/10W R843 RGF10001TCANL MT-GLAZE 100 JA 1/10W R1010 RGF1000LTCANL MT-GLAZE 220 JA 1/10W R844 R6F1000JTCANL MT-GLAZE 100 JA 1/10W R1010 RGF1000LTCANL MT-GLAZE 100 JA 1/10W R846 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1011 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R847 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1021 RGF78R0JTCANL MT-GLAZE 100 JA 1/10W R848 RGF860JTCANL MT-GLAZE 100 JA 1/10W R1022 RGF78R0JTCANL MT-GLAZE 75 JA 1/10W R849 RGF1003JTCANL MT-GLAZE 100K JA 1/10W R1025 RGF78R0JTCANL MT-GLAZE 75 JA 1/10W R850 RGF1003JTCANL MT-GLAZE 100K JA 1/10W R1025 RGF78R0JTCANL MT-GLAZE 470K JA 1/10W R851 RGF1003JTCANL MT-GLAZE 100K JA 1/10W R1025 RGF78R0JTCANL MT-GLAZE 470K JA 1/10W R853 RGF1003JTCANL MT-GLAZE 100K JA 1/10W R1025 RGF78R0JTCANL MT-GLAZE 470K JA 1/10W R854 RGF770JTCANL MT-GLAZE 100K JA 1/10W R1025 RGF78R0JTCANL MT-GLAZE 470K JA 1/10W R855 RGF770JTCANL MT-GLAZE 100K JA 1/10W R1025 RGF78DJTCANL MT-GLAZE 470K JA 1/10W R856 RGF770JTCANL MT-GLAZE 470K JA 1/10W R1025 RGF78DJTCANL MT-GLAZE 470K JA 1/10W R858 RGF1003JTCANL MT-GLAZE 10K JA 1/10W R1029 RGF7R0JTCANL MT-GLAZE 470K JA 1/10W R1036 RGF1000JTCANL MT-GLAZE 10K JA 1/10W	R834	RGF2701JTCANL	MT-GLAZE	2.7K JA 1/10W	R1004	RGF4703JTCANL	MT-GLAZE	470K JA 1/10W
R841 RGF10001TCANL		RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		RGF4703JTCANL		470K JA 1/10W
R841 RGF1000LTCANIL MT-GLAZE 100 JA 1/10W R1008 RGF2200LTCANIL MT-GLAZE 220 JA 1/10W R843 RGF1000LTCANIL MT-GLAZE 100 JA 1/10W R1010 RGF2200LTCANIL MT-GLAZE 100 JA 1/10W R844 RGF1000LTCANIL MT-GLAZE 100 JA 1/10W R1011 RGF100DLTCANIL MT-GLAZE 100 JA 1/10W R847 RGF601DLTCANIL MT-GLAZE 100 JA 1/10W R1021 RGF760DLTCANIL MT-GLAZE 75 JA 1/10W R848 RGF600LTCANIL MT-GLAZE 5.6K JA 1/10W R1022 RGF75ROLTCANIL MT-GLAZE 75 JA 1/10W R849 RGF1003LTCANIL MT-GLAZE 100K JA 1/10W R1023 RGF75ROLTCANIL MT-GLAZE 75 JA 1/10W R850 RGF1003LTCANIL MT-GLAZE 100K JA 1/10W R1023 RGF470SLTCANIL MT-GLAZE 170K JA 1/10W R851 RGF1003LTCANIL MT-GLAZE 100K JA 1/10W R1025 RGF470SLTCANIL MT-GLAZE 470K JA 1/10W R853 RGF470LTCANIL MT-GLAZE 10K JA 1/10W		RGF1000JTCANL				RGF2200JTCANL		
R842 R6F1000LTCANL MT-GLAZE 100 JA 1/10W R1009 R6F2200LTCANL MT-GLAZE 20 JA 1/10W R844 R6F1000LTCANL MT-GLAZE 100 JA 1/10W R1011 R6F1000LTCANL MT-GLAZE 100 JA 1/10W R847 R6F1000LTCANL MT-GLAZE 100 JA 1/10W R1021 R6F760DLTCANL MT-GLAZE 100 JA 1/10W R848 R6F601DLTCANL MT-GLAZE 5.6K JA 1/10W R1022 R6F760DLTCANL MT-GLAZE 75 JA 1/10W R849 R6F1003LTCANL MT-GLAZE 100K JA 1/10W R1023 R6F760DLTCANL MT-GLAZE 75 JA 1/10W R850 R6F1003LTCANL MT-GLAZE 100K JA 1/10W R1025 R6F4703LTCANL MT-GLAZE 470K JA 1/10W R851 R6F1003LTCANL MT-GLAZE 100K JA 1/10W R1022 R6F4703LTCANL MT-GLAZE 470K JA 1/10W R1028 R6F4703LTCANL <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>								
R843 RGF1000LTCANIL MT-GLAZE 100 JA 1/10W R1010 RGF1000LTCANIL MT-GLAZE 100 JA 1/10W R846 RGF1000LTCANIL MT-GLAZE 100 JA 1/10W R1021 RGF100LTCANIL MT-GLAZE 100 JA 1/10W R847 RGF5601LTCANIL MT-GLAZE 5.6K JA 1/10W R1022 RGF75R0LTCANIL MT-GLAZE 7.5 JA 1/10W R848 RGF61003LTCANIL MT-GLAZE 5.6K JA 1/10W R1023 RGF75R0LTCANIL MT-GLAZE 7.5 JA 1/10W R850 RGF1003LTCANIL MT-GLAZE 100K JA 1/10W R1023 RGF76R0LTCANIL MT-GLAZE 470K JA 1/10W R851 RGF1003LTCANIL MT-GLAZE 100K JA 1/10W R1025 RGF478DLTCANIL MT-GLAZE 470K JA 1/10W R1026 RGF478DLTCANIL MT-GLAZE 470K JA 1/10W R1028 RGF478DLTCANIL MT-GLAZE 470K JA 1/10W R1038 RGF478DLTCANIL MT-GLAZE 470K JA 1/10W R1038 RGF478DLTCANIL MT-GLAZE 470K JA 1/10W R1031 RGF478DLTCANIL MT-GLAZE 470K JA 1/10W R1031 RGF478DLTCANI								
R844 R6F1000,TCANL								
R846 R6F1000_TCANL								
R847 R6F5601JTCANL								
R848								
R849 R6F1003,TCANL MT-GLAZE 100K JA 1/10W R1024 R6F4703,TCANL MT-GLAZE 470K JA 1/10W R851 R6F1003,TCANL MT-GLAZE 100K JA 1/10W R1027 R6F4703,TCANL MT-GLAZE 470K JA 1/10W R853 R6F1002,TCANL MT-GLAZE 100K JA 1/10W R1028 R6F47R0,TCANL MT-GLAZE 47 JA 1/10W R854 R6F4701,TCANL MT-GLAZE 4,7K JA 1/10W R1028 R6F47R0,TCANL MT-GLAZE 47 JA 1/10W R855 R6F4701,TCANL MT-GLAZE 4,7K JA 1/10W R1030 R6F1000,TCANL MT-GLAZE 10 JA 1/10W R858 R6F1002,TCANL MT-GLAZE 10K JA 1/10W R1032 R6F1202,TCANL MT-GLAZE 12K JA 1/10W R860 R6F1002,TCANL MT-GLAZE 10K JA 1/10W R1032 R6F1202,TCANL MT-GLAZE 12K JA 1/10W R861 R6F1000,TCANL MT-GLAZE 10K JA 1/10W R1035 R6F1202,TCANL MT-GLAZE 12K JA 1/10W R864 R6F1000,TCANL MT-GLAZE 10K JA 1/10W R1035<								
R850 R6F1003,TCANL MT-GLAZE 100K JA 1/10W R1027 R6F47R3JTCANL MT-GLAZE 47 JA 1/10W R851 R6F1002,TCANL MT-GLAZE 10K JA 1/10W R1028 R6F47R0JTCANL MT-GLAZE 47 JA 1/10W R854 R6F4701,TCANL MT-GLAZE 47 KJA 1/10W R1028 R6F47R0JTCANL MT-GLAZE 47 JA 1/10W R855 R6F4701,TCANL MT-GLAZE 4,7K JA 1/10W R1039 R6F1000,TCANL MT-GLAZE 10 JA 1/10W R856 R6F4701,TCANL MT-GLAZE 10 KJA 1/10W R1031 R6F1000,TCANL MT-GLAZE 10 JA 1/10W R859 R6F1002,TCANL MT-GLAZE 10 KJA 1/10W R1032 R6F1202,TCANL MT-GLAZE 10 KJA 1/10W R1033 R6F1202,TCANL MT-GLAZE 12 KJA 1/10W R1035 R6F1202,TCANL MT-GLAZE 12 KJA 1/10W R1035 R6F1202,TCANL MT-GLAZE 12 KJA 1/10W R1035 R6F1202,TCANL MT-GLAZE 12 KJA 1/10W R1036 R6F1202,TCANL MT-GLAZE 12 KJA 1/10W R1036 R6F1202,TCANL MT-GLAZE								
R851 RGF1002JTCANL MT-GLAZE 100K JA 1/10W R1027 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R854 RGF4701JTCANL MT-GLAZE 47 KJA 1/10W R1028 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R855 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1030 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R856 RGF4701JTCANL MT-GLAZE 10K JA 1/10W R1030 RGF100DJTCANL MT-GLAZE 10K JA 1/10W R859 RGF100ZJTCANL MT-GLAZE 10K JA 1/10W R1032 RGF120ZJTCANL MT-GLAZE 12K JA 1/10W R860 RGF100ZJTCANL MT-GLAZE 10K JA 1/10W R1033 RGF120ZJTCANL MT-GLAZE 12K JA 1/10W R861 RGF100ZJTCANL MT-GLAZE 10K JA 1/10W R1035 RGF120ZJTCANL MT-GLAZE 12K JA 1/10W R863 RGF100DJTCANL MT-GLAZE 10K JA 1/10W R1035 RGF120ZJTCANL MT-GLAZE 12K JA 1/10W R861 RGF100DJTCANL MT-GLAZE 10K JA 1/10W R1035								
R853 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1028 RGF470JTCANL MT-GLAZE 47, JA 1/10W R854 RGF470JTCANL MT-GLAZE 4,7K JA 1/10W R1029 RGF470JTCANL MT-GLAZE 47, JA 1/10W R856 RGF470JTCANL MT-GLAZE 4,7K JA 1/10W R1031 RGF100DJTCANL MT-GLAZE 100 JA 1/10W R858 RGF100ZJTCANL MT-GLAZE 10K JA 1/10W R1032 RGF120ZJTCANL MT-GLAZE 12K JA 1/10W R860 RGF100ZJTCANL MT-GLAZE 10K JA 1/10W R1033 RGF120ZJTCANL MT-GLAZE 12K JA 1/10W R861 RGF100ZJTCANL MT-GLAZE 10K JA 1/10W R1034 RGF120ZJTCANL MT-GLAZE 12K JA 1/10W R863 RGF100DJTCANL MT-GLAZE 100 JA 1/10W R1036 RGF120ZJTCANL MT-GLAZE 12K JA 1/10W R865 RGF100DJTCANL MT-GLAZE 100 JA 1/10W R1036 RGF120ZJTCANL MT-GLAZE 12K JA 1/10W R865 RGF100DJTCANL MT-GLAZE 100 JA 1/10W R1036								
R854 R6F4701JTCANL R855 MT-GLAZE R6F4701JTCANL MT-GLAZE 4.7K JA 1/10W R1030 R6F1000JTCANL R6F1000JTCANL MT-GLAZE MT-GLAZE 100 JA 1/10W R1031 MT-GLAZE R6F1000JTCANL MT-GLAZE 4.7K JA 1/10W R1031 R6F1000JTCANL R6F1000JTCANL MT-GLAZE MT-GLAZE 10K JA 1/10W R1032 MT-GLAZE R6F1202JTCANL MT-GLAZE MT-GLAZE 12K JA 1/10W R1033 MT-GLAZE R6F1202JTCANL MT-GLAZE MT-GLAZE 12K JA 1/10W R1034 MT-GLAZE R6F1202JTCANL MT-GLAZE MT-GLAZE 12K JA 1/10W R1035 MT-GLAZE R6F120ZJTCANL MT-GLAZE MT-GLAZE 10D JA 1/10W R1038 MT-GLAZE R6F120ZJTCANL MT-GLAZE MT-GLAZE 10D JA 1/10W R1038 MT-GLAZE R6F360DJTCANL MT-GLAZE MT-GLAZE 10D JA 1/10W R1041 <								
R855 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1030 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R856 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1031 RGF1000JTCANL MT-GLAZE 10K JA 1/10W R1032 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1033 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R860 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1033 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R1036 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R1035 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R1035 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R1036 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R1036 RGF120CJTCANL MT-GLAZE 12K JA 1/10W R1036 RGF								
R856 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1031 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R858 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1032 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R850 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1034 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R861 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1036 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R863 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1036 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R864 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1037 RGF120ZJTCANL MT-GLAZE 12K JA 1/10W R865 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1038 RGF470TLCANL MT-GLAZE 100 JA 1/10W R1038 RGF470TLCANL MT-GLAZE 47 JA 1/10W R866 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1048 RGF470TLCANL MT-GLAZE 400 JA 1/10W R1048 RGF470TL								
R858 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1032 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R859 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1033 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R861 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1034 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R863 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1036 RGF120ZJTCANL MT-GLAZE 12K JA 1/10W R865 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1038 RGF120CJTCANL MT-GLAZE 12K JA 1/10W R866 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1038 RGF5600JTCANL MT-GLAZE 100 JA 1/10W R867 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1039 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R867 RGF1000JTCANL MT-GLAZE 4.7K JA 1/10W R1041 RGF470JTCANL MT-GLAZE 47 JA 1/10W R873 RGF100DJTCANL MT-GLAZE 100 JA 1/10W R1042								
R859 RGF1002JTCANL R860 MT-GLAZE 10K JA 1/10W R1033 RGF1202JTCANL R61 MT-GLAZE 12K JA 1/10W R861 RGF1002JTCANL R863 MT-GLAZE 10K JA 1/10W R1035 RGF1202JTCANL R663 MT-GLAZE 12K JA 1/10W R864 RGF1000JTCANL R865 MT-GLAZE 10D JA 1/10W R1036 RGF1202JTCANL R661 MT-GLAZE 12K JA 1/10W R866 RGF1000JTCANL R866 MT-GLAZE 100 JA 1/10W R1038 RGF600DJTCANL R666 MT-GLAZE 100 JA 1/10W R1038 RGF600DJTCANL R761 MT-GLAZE 100 JA 1/10W R1038 RGF600DJTCANL R761 MT-GLAZE 100 JA 1/10W R1038 RGF600DJTCANL R761 MT-GLAZE 100 JA 1/10W R1049 R1040 MT-GLAZE 47 JA 1/10W R1041 RGF6470JTCANL R761 MT-GLAZE 47 JA 1/10W R1041 RGF6500JTCANL R761 MT-GLAZE 47 JA 1/10W R1042 RGF6600JTCANL R761 MT-GLAZE 47 JA 1/10W R1042 RGF6600JTCANL R761 MT-GLAZE 47 JA 1/10W R1042 RGF6600JTCANL R761 MT-GLAZE 47 JA 1/10W R1042 RGF6600JTCAN								
R860 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1034 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R861 RGF1000JTCANL MT-GLAZE 10K JA 1/10W R1036 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R864 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1036 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R865 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1037 RGF5600JTCANL MT-GLAZE 12K JA 1/10W R866 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1039 RGF4760JTCANL MT-GLAZE 560 JA 1/10W R867 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1040 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R870 RGF100DJTCANL MT-GLAZE 4.7K JA 1/10W R1042 RGF5600JTCANL MT-GLAZE 47JA 1/10W R873 RGF100DJTCANL MT-GLAZE 4.7K JA 1/10W R1043 RGF470JTCANL MT-GLAZE 560 JA 1/10W R874 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1062								
R861 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1035 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R863 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1036 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R865 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1038 RGF2600JTCANL MT-GLAZE 560 JA 1/10W R866 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1039 RGF47R0JTCANL MT-GLAZE 560 JA 1/10W R867 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1040 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R870 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1041 RGF47R0JTCANL MT-GLAZE 4.7K JA 1/10W R873 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1042 RGF5600JTCANL MT-GLAZE 40 JA 1/10W R875 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1061 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R876 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1063								
R863 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1037 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R864 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1037 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R866 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1038 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R866 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1039 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R867 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1040 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R868 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1041 RGF47R0JTCANL MT-GLAZE 560 JA 1/10W R870 RGF1000JTCANL MT-GLAZE 4.7K JA 1/10W R1041 RGF47R0JTCANL MT-GLAZE 560 JA 1/10W R873 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1041 RGF47R0JTCANL MT-GLAZE 560 JA 1/10W R874 RGF1000JTCANL MT-GLAZE 4.7K JA 1/10W R1061 RGF75R0JTCANL MT-GLAZE 47 JA 1/10W R875 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1061 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R875 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1062 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R888 RGF8000ZTCANL MT-GLAZE 100 JA 1/10W R1063 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R884 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1064 RGF47R0JTCANL MT-GLAZE 470K JA 1/10W R884 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1064 RGF47R0JTCANL MT-GLAZE 470K JA 1/10W R885 RGF8000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1065 RGF47R0JTCANL MT-GLAZE 470K JA 1/10W R885 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1067 RGF47R0JTCANL MT-GLAZE 470K JA 1/10W R1068 RGF47R0JTCANL MT-GLAZE 470K JA 1/10W R1068 RGF47R0JTCANL MT-GLAZE 470K JA 1/10W R1068 RGF47R0JTCANL MT-GLAZE 470K JA 1/10W R1069 RGF47R0JTCANL MT-GLAZE 470K JA 1/10W R1071 RGF1000JTCANL MT-GLAZE 470K JA 1/10W R1071 RGF1000JTCANL MT-GLAZE 470K JA 1/10W R1072 RGF1202JTCANL MT-GLAZE 100 JA 1/10W R1072 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R1073 RGF1202JTCANL MT-GLAZE 12K JA 1/1								
R864 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1037 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R865 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1038 RGF5600JTCANL MT-GLAZE 450 JA 1/10W R867 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1039 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R868 RGF4701JTCANL MT-GLAZE 47 KJA 1/10W R1041 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R870 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1041 RGF47R0JTCANL MT-GLAZE 560 JA 1/10W R874 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1042 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R875 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1061 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R876 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1062 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R876 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1063								
R865 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1038 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R866 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1039 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R867 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1040 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R870 RGF1000JTCANL MT-GLAZE 4.7K JA 1/10W R1041 RGF47R0JTCANL MT-GLAZE 560 JA 1/10W R873 RGF4701JTCANL MT-GLAZE 100 JA 1/10W R1043 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R874 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1061 RGF5780JTCANL MT-GLAZE 75 JA 1/10W R875 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1062 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R876 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1063 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R883 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1064								
R866 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1039 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R867 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1040 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R868 RGF4701JTCANL MT-GLAZE 4.7 K JA 1/10W R1041 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R873 RGF4701JTCANL MT-GLAZE 4.7 K JA 1/10W R1043 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R874 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1061 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R876 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1063 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R886 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1063 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R881 RGF1000JTCANL MT-GLAZE 0.000 ZA 1/10W R1064 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R884 RGF000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1064 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>								
R867 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1040 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R868 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1041 RGF470JTCANL MT-GLAZE 47 JA 1/10W R870 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1042 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R874 RGF100JTCANL MT-GLAZE 4.7K JA 1/10W R1043 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R875 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1062 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R876 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1063 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R884 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1065 RGF470JTCANL MT-GLAZE 470K JA 1/10W R885 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1065 RGF47R0JTCANL MT-GLAZE 470K JA 1/10W R884 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1067 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>								
R868 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1041 RGF470JTCANL MT-GLAZE 47 JA 1/10W R870 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1042 RGF6600JTCANL MT-GLAZE 560 JA 1/10W R873 RGF470JTCANL MT-GLAZE 4.7K JA 1/10W R1043 RGF470JTCANL MT-GLAZE 47 JA 1/10W R874 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1061 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R876 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1063 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R883 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1064 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R884 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1065 RGF470JTCANL MT-GLAZE 470K JA 1/10W R885 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1068 RGF47R0JTCANL MT-GLAZE 470K JA 1/10W R885 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1069 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>								
R870 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1042 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R873 RGF470JJTCANL MT-GLAZE 4.7K JA 1/10W R1043 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R874 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1061 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R875 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1062 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R883 RGF7000JTCANL MT-GLAZE 100 JA 1/10W R1063 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R884 RGF7000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1063 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R885 RGF1000JTCANL MT-GLAZE 0.000 ZA 1/10W R1065 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R888 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1068 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R889 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1069 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>								
R873 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1043 RGF47R0JTCANL MT-GLAZE 4.7 JA 1/10W R874 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1061 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R875 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1062 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R886 RGF1000JTCANL MT-GLAZE 0.000 ZA 1/10W R1063 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R884 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1065 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R885 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1065 RGF47R0JTCANL MT-GLAZE 470K JA 1/10W R887 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1068 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R888 RGF1004JTCANL MT-GLAZE 100 JA 1/10W R1068 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R893 RGF1004JTCANL MT-GLAZE 100 JA 1/10W R1069<								
R875 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1062 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R876 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1063 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R883 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1064 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R884 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1065 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R885 RGF1000JTCANL MT-GLAZE 0.000 ZA 1/10W R1067 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R887 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1068 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R888 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1069 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R889 RGF1002JTCANL MT-GLAZE 100 JA 1/10W R1070 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R894 RGF1002JTCANL MT-GLAZE 100 JA 1/10W R1072 </td <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>								
R876 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1063 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R883 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1064 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R884 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1065 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R885 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1067 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R887 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1068 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R888 RGF1004JTCANL MT-GLAZE 100 JA 1/10W R1069 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R889 RGF1002JTCANL MT-GLAZE 10M JA 1/10W R1070 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R894 RGF1000JTCANL MT-GLAZE 10K JA 1/10W R1072 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R895 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R1073	R874	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W	R1061	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W
R883 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1064 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R884 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1065 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R885 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1067 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R887 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1068 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R888 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1069 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R889 RGF1004JTCANL MT-GLAZE 100 JA 1/10W R1070 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R894 RGF1000JTCANL MT-GLAZE 10K JA 1/10W R1072 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R895 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R1073 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R897 CK1H103ZLFNG CERAMIC 0.01U Z 50V	R875	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W	R1062	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W
R884 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1065 RGF4703JTCANL MT-GLAZE 470 K JA 1/10W R885 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1067 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R887 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1068 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R888 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1069 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R889 RGF1004JTCANL MT-GLAZE 100 JA 1/10W R1070 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R893 RGF1002JTCANL MT-GLAZE 100 JA 1/10W R1071 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R894 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1072 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R895 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R1073 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R896 RGF3901JTCANL MT-GLAZE 3.9K JA 1/10W R1074	R876	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W	R1063	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W
R885 RGFR000ZTCANL MT-GLAZE 0.000 ZA 1/10W R1067 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R887 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1068 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R888 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1069 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R889 RGF1004JTCANL MT-GLAZE 1 M JA 1/10W R1070 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R893 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1071 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R894 RGF1000JTCANL MT-GLAZE 10K JA 1/10W R1072 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R895 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R1073 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R896 RGF3901JTCANL MT-GLAZE 3.9K JA 1/10W R1074 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R897 CK1H103ZLZFNG CERAMIC 0.01U Z 50V	R883	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W	R1064	RGF4703JTCANL	MT-GLAZE	470K JA 1/10W
R887 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1068 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R888 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1069 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R889 RGF1004JTCANL MT-GLAZE 1M JA 1/10W R1070 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R893 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1071 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R894 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1072 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R895 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R1073 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R896 RGF3901JTCANL MT-GLAZE 3.9K JA 1/10W R1074 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R897 CK1H103ZLZFNG CERAMIC 0.01U Z 50V R1075 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R899 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1076	R884	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W	R1065	RGF4703JTCANL	MT-GLAZE	470K JA 1/10W
R888 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1069 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R889 RGF1004JTCANL MT-GLAZE 1M JA 1/10W R1070 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R893 RGF1000JTCANL MT-GLAZE 10K JA 1/10W R1071 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R894 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1072 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R895 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R1073 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R896 RGF3901JTCANL MT-GLAZE 3.9K JA 1/10W R1074 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R897 CK1H103ZLZFNG CERAMIC 0.01U Z 50V R1075 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R899 RGF1000JTCANL MT-GLAZE 10K JA 1/10W R1076 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R900 RGF1000JTCANL MT-GLAZE 10K JA 1/10W R1076	R885	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W	R1067	RGF47R0JTCANL	MT-GLAZE	
R889 RGF1004JTCANL MT-GLAZE 1 M JA 1/10W R1070 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R893 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1071 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R894 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1072 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R895 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R1073 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R896 RGF3901JTCANL MT-GLAZE 3.9K JA 1/10W R1074 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R897 CK1H103ZLZFNG CERAMIC 0.01U Z 50V R1075 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R899 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1076 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R900 RGF1000JTCANL MT-GLAZE 10K JA 1/10W R1077 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R901 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W		RGF1000JTCANL	MT-GLAZE	100 JA 1/10W	R1068	RGF47R0JTCANL	MT-GLAZE	47 JA 1/10W
R893 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1071 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R894 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1072 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R895 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R1073 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R896 RGF3901JTCANL MT-GLAZE 3.9K JA 1/10W R1074 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R897 CK1H103ZLZFNG CERAMIC 0.01U Z 50V R1075 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R899 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1075 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R900 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1077 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R901 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1078 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R902 RGF1002JTCANL MT-GLAZE 10K JA 1/10W								
R894 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1072 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R895 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R1073 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R896 RGF3901JTCANL MT-GLAZE 3.9K JA 1/10W R1074 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R897 CK1H103ZLZFNG CERAMIC 0.01U Z 50V R1075 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R899 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1076 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R900 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1077 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R901 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1078 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R902 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1079 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R903 RGF3302JTCANL MT-GLAZE 33K JA 1/10W								
R895 RGF4703JTCANL MT-GLAZE 470K JA 1/10W R1073 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R896 RGF3901JTCANL MT-GLAZE 3.9K JA 1/10W R1074 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R897 CK1H103ZLZFNG CERAMIC 0.01U Z 50V R1075 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R899 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1076 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R900 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1077 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R901 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1078 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R902 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1079 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R903 RGF3302JTCANL MT-GLAZE 33K JA 1/10W R1080 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R904 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W								
R896 RGF3901JTCANL MT-GLAZE 3.9K JA 1/10W R1074 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R897 CK1H103ZLZFNG CERAMIC 0.01U Z 50V R1075 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R899 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1076 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R900 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1077 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R901 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1078 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R902 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1079 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R903 RGF3302JTCANL MT-GLAZE 33K JA 1/10W R1080 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R904 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1081 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R905 RGF4701JTCANL MT-GLAZE 56 JA 1/10W								
R897 CK1H103ZLZFNG CERAMIC 0.01U Z 50V R1075 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R899 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1076 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R900 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1077 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R901 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1078 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R902 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1079 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R903 RGF3302JTCANL MT-GLAZE 33K JA 1/10W R1080 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R904 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1081 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R905 RGF4701JTCANL MT-GLAZE 56 JA 1/10W R1083 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R906 RGF56R0JTCANL MT-GLAZE 56 JA 1/10W <t< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></t<>								
R899 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1076 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R900 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1077 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R901 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1078 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R902 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1079 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R903 RGF3302JTCANL MT-GLAZE 33K JA 1/10W R1080 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R904 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1081 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R905 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1082 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R906 RGF56R0JTCANL MT-GLAZE 56 JA 1/10W R1083 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W								
R900 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1077 RGF1202JTCANL MT-GLAZE 12K JA 1/10W R901 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1078 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R902 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1079 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R903 RGF3302JTCANL MT-GLAZE 33K JA 1/10W R1080 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R904 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1081 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R905 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1082 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R906 RGF56R0JTCANL MT-GLAZE 56 JA 1/10W R1083 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W								
R901 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1078 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R902 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1079 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R903 RGF3302JTCANL MT-GLAZE 33K JA 1/10W R1080 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R904 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1081 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R905 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1082 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R906 RGF56R0JTCANL MT-GLAZE 56 JA 1/10W R1083 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W								
R902 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1079 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R903 RGF3302JTCANL MT-GLAZE 33K JA 1/10W R1080 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R904 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1081 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R905 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1082 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R906 RGF56R0JTCANL MT-GLAZE 56 JA 1/10W R1083 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W								
R903 RGF3302JTCANL MT-GLAZE 33K JA 1/10W R1080 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R904 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1081 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R905 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1082 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R906 RGF56R0JTCANL MT-GLAZE 56 JA 1/10W R1083 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W								
R904 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1081 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W R905 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1082 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R906 RGF56R0JTCANL MT-GLAZE 56 JA 1/10W R1083 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W								
R905 RGF4701JTCANL MT-GLAZE 4.7K JA 1/10W R1082 RGF5600JTCANL MT-GLAZE 560 JA 1/10W R906 RGF56R0JTCANL MT-GLAZE 56 JA 1/10W R1083 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W								
R906 RGF56R0JTCANL MT-GLAZE 56 JA 1/10W R1083 RGF47R0JTCANL MT-GLAZE 47 JA 1/10W								
HOUT HOLFTO TO TO MILE IN TO CALL 4.7K ON 1/10W NTOUT NOTOZOUJI ONIT UNITULAZE 020 JA 1/10W								
R908 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1102 RGF8200JTCANL MT-GLAZE 820 JA 1/10W								
R909 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1102 RGF8200JTCANL MT-GLAZE 820 JA 1/10W R909 RGF1000JTCANL MT-GLAZE 100 K JA 1/10W								
R1001 RGF75R0JTCANL MT-GLAZE 700 JA 1/10W R1103 RGF1003JTCANL MT-GLAZE 100K JA 1/10W								
R1002 RGF75R0JTCANL MT-GLAZE 75 JA 1/10W R1105 RGF1001JTCANL MT-GLAZE 1K JA 1/10W								

Schematic Location	Part No.	De	scription		Schematic Location	Part No.	De	scription
R1106	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W	•	R3419	RGF6802FTCANL	MT-GLAZE	68K FA 1/10W
R1201	RGF47R0JTCANL	MT-GLAZE	47 JA 1/10W		R3420	RGF3301JTCANL	MT-GLAZE	3.3K JA 1/10W
R1202	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		R3421	RGF3001JTCANL	MT-GLAZE	3K JA 1/10W
R1203	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		R3422	RGF3901JTCANL	MT-GLAZE	3.9K JA 1/10W
R1204	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W		R3425	RGF47R0JTCANL	MT-GLAZE	47 JA 1/10W
R1205	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		R3426	RGF47R0JTCANL	MT-GLAZE	47 JA 1/10W
R1206	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		R3427	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W
R1207	RGF47R0JTCANL	MT-GLAZE	47 JA 1/10W		R3428	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R1208	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		R3431	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W
R1209	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		R3432	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R1210	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W		R3439	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R1253	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W		R3440	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R1254	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W					
R1255	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W					
R1256	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W			SURGE-ABS	ORBER	
R1257	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		SC1001	1AV4Z30B0220G	SURGE-ABS	ORBER
R1260	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W		SC1002	1AV4Z30B0220G	SURGE-ABS	ORBER
R1261	RGF2203JTCANL	MT-GLAZE	220K JA 1/10W		SC1003	1AV4Z30B0220G	SURGE-ABS	ORBER
R1262	RGF2203JTCANL	MT-GLAZE	220K JA 1/10W		SC1004	1AV4Z30B0220G	SURGE-ABS	ORBER
R1263	RGF2203JTCANL	MT-GLAZE	220K JA 1/10W		SC1005	1AV4Z30B0220G	SURGE-ABS	ORBER
R1264	RGF2203JTCANL	MT-GLAZE	220K JA 1/10W		SC1006	1AV4Z30B0220G	SURGE-ABS	ORBER
R1265	RGF2203JTCANL	MT-GLAZE	220K JA 1/10W		SC1021	1AV4Z30B0220G	SURGE-ABS	ORBER
R1266	RGF2203JTCANL	MT-GLAZE	220K JA 1/10W		SC1022	1AV4Z30B0220G	SURGE-ABS	ORBER
R1267	RGF2203JTCANL	MT-GLAZE	220K JA 1/10W		SC1023	1AV4Z30B0220G	SURGE-ABS	ORBER
R1268	RGF2203JTCANL	MT-GLAZE	220K JA 1/10W		SC1024	1AV4Z30B0220G	SURGE-ABS	ORBER
R1269	RGF2203JTCANL	MT-GLAZE	220K JA 1/10W		SC1025	1AV4Z30B0220G	SURGE-ABS	ORBER
R1270	RGF2203JTCANL	MT-GLAZE	220K JA 1/10W		SC1061	1AV4Z30B0220G	SURGE-ABS	
R1271	RGF2203JTCANL	MT-GLAZE	220K JA 1/10W		SC1062	1AV4Z30B0220G	SURGE-ABS	
R1272	RGF2203JTCANL	MT-GLAZE	220K JA 1/10W		SC1063	1AV4Z30B0220G	SURGE-ABS	
R1605	RGF3302JTCANL	MT-GLAZE	33K JA 1/10W		SC1064	1AV4Z30B0220G	SURGE-ABS	
R1606	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		SC1065	1AV4Z30B0220G	SURGE-ABS	
★ R1609	RG11R20JTEANL	MT-GLAZE	1.2 JA 1W		SC1101	1AV4Z30B0220G	SURGE-ABS	
R1610	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W 2.2 JA 1W		SC1102	1AV4Z30B0220G	SURGE-ABS	
★ R1626 R1802	RG12R20JTEANL RGF1000JTCANL	MT-GLAZE MT-GLAZE	100 JA 1/10W		SC1801	1AV4Z30B0220G	SURGE-ABS	
R1803	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		SC1802	1AV4Z30B0220G	SURGE-ABS	
R1804	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		SC1803 SC1804	1AV4Z30B0220G 1AV4Z30B0220G	SURGE-ABS	
R1805	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W		SC1804 SC1805	1AV4Z30B0220G	SURGE-ABS	
R1806	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W		SC1806	1AV4Z30B0220G	SURGE-ABS	
R1807	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		SC1807	1AV4Z30B02Z0G	SURGE-ABS	
R1809	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W		301007	1AV4230D02200	SUNGL-ADS	ONDEN
R1812	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W					
R1813	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W			CRYSTAL / O	SCILL ATOR	29
R1814	RGF8200JTCANL	MT-GLAZE	820 JA 1/10W		X801	1AV4V10B0560N		AL 32.768KHZ
R1815	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W		7,001	1AV4V10B0570N		AL 32.768KHZ
R1816	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W			1717 17 10 0007 014	000, 011101	AL OLITOORITE
R1817	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W					
R1819	RGE1000JTBANL	MT-GLAZE	100 JA 1/8W			MISCELLANE	OUS	
R3401	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		★ A101	1AV4F1FAM0170	TUNER, TU/I	F
R3402	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		A801	1AA0B10N2020A	ASSY, PWB,	
R3403	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		K1001	1AV4J31B07700	TERMINAL, I	
R3404	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		K1021	1AV4J12B3960N	JACK, RCA-5	
R3405	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W		K1061	1AV4J12B3960N	JACK, RCA-5	' '
R3406	RGF1004JTCANL	MT-GLAZE	1M JA 1/10W		K1101	1AV4J12B3970N	JACK, RCA-2	
R3407	RGF1003JTCANL	MT-GLAZE	100K JA 1/10W			1LB4J12B08100	JACK, RCA-2	
R3416	RGF1501JTCANL	MT-GLAZE	1.5K JA 1/10W				•	
R3417	RGF1801JTCANL	MT-GLAZE	1.8K JA 1/10W					
R3418	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W					

Schematic	Part No.	Description
Location	rait No.	Description

FILTER PC BOARD

CAPACITORS

★ C602 MT-POLYEST 0.22U M CGXAV27224CAN 275V **★** C606 CKXAV2E102AAC CERAMIC 1000P M 250V **★** C607 CKXAV2E102AAC CERAMIC 1000P M 250V

COILS

★ LF601 1AV4F35B1390N LINE FILTER ★ LF602 1AV4F35B1390N LINE FILTER

MISCELLANEOUS

★ SC601 1AV4Z30B0170N SURGE-ABSORBER VARISTOR ENC471D-14AS **★** VA601 DVXAAEV0043--**★** VA602 DVXAAEV0047--VARISTOR ENC271D-10AS A600 1AA0B10N20300 ASSY, PWB, FILTER-J3TZ **FUSE 250V 10A** ★ F601 F32S10RA2LTTL F601A 1AV4J20B0040N HOLDER, FUSE F601B 1AV4J20B0040N HOLDER, FUSE K601 1AV4U20B61300 UNIT, NOISE FILTER

CONTROL PC BOARD

CAPACITORS

C1902 CK1H102KLZBNG CERAMIC 1000P K 50V C1903 CK0J106KGMBNG CERAMIC 10U K 6.3V C1904 CK0J106KGMBNG **CERAMIC** 10U K 6.3V

DIODES

D1903 DLSLP-381C51N LED SLP-381C-51 D1903A 1AV2SA9SD01K-**SPACER**

RESISTORS

0.000 ZA 1/10W R1900 RGFR000ZTCANL MT-GLAZE R1916 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1917 MT-GLAZE RGF1000JTCANL 100 JA 1/10W

SURGE-ABSORBERS

SC1901 1AV4Z30B0220G SURGE-ABSORBER SC1902 1AV4Z30B0220G SURGE-ABSORBER

MISCELLANEOUS

1AA0B10N2020B A1901 ASSY, PWB, CONTROL J3TZ A1902 1AV4U20B24401 UNIT, REMOCON RECEIVER

Schematic Location

Part No.

Description

KEY SWITCH PC BOARD

CAPACITORS

C1951 CK1E104ZLZFNG CERAMIC 0.1U Z 25V

DIODES

D1957 DZUDZS10B---G ZENER DIODE UDZS10B TE-17 D1958 DZUDZS10B---G ZENER DIODE UDZS10B TE-17

COILS

L1955 1AV4L26B0130G INDUCTOR, 600 OHM

RESISTORS

R1953 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1954 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1956 MT-GLAZE RGF1001JTCANL 1K JA 1/10W RGF1001JTCANL MT-GLAZE R1957 1K JA 1/10W R1958 RGF1002JTCANL MT-GLAZE 10K JA 1/10W R1959 RGF1801JTCANL MT-GLAZE 1.8K JA 1/10W R1961 RGF2201JTCANL MT-GLAZE 2.2K JA 1/10W R1962 RGF3901JTCANL MT-GLAZE 3.9K JA 1/10W R1963 RGF5601JTCANL MT-GLAZE 5.6K JA 1/10W

SWITCHES

SW1951 1AV4S10B3530G SWITCH, PUSH 1P-1TX1 SW1952 1AV4S10B3530G SWITCH, PUSH 1P-1TX1 SW1953 1AV4S10B3530G SWITCH, PUSH 1P-1TX1 SW1954 1AV4S10B3530G SWITCH, PUSH 1P-1TX1 SW1955 1AV4S10B3530G SWITCH, PUSH 1P-1TX1

MISCELLANEOUS

A1951 1AA0B10N2020C ASSY, PWB, KEY_SW J3TZ

DIGITAL PC BOARD


ASSY, PWB, DIGITAL-J3TZ A5500 1AA0B10N20400 Nonservicable part. No discreet parts provided for this pc board.

MISCELLANEOUS

★ EL901 1AV4T44B01700 PDP MODULE / POWER SUPPLY

★ U901 UNIT. PDP-LOGIC 1AV4U20C02100 SP901 SPEAKER 8 1LB4A10B05700

CABINET PARTS LIST




CABINET PARTS LIST


ACCESSORY PARTS LIST

KEY NO.	PARTS NO.	DESCRIPTION	KEY NO.	PARTS NO.	DESCRIPTION
1	1AA2CAM0493-F	CABINET FRONT		1AA6P1P5111	OWNERS MANUAL (ENG/SPA)
★ 2	1AV4Z12B38600	EL902 OPTICAL FILTER		1JC6P1P0218	OWNERS MANUAL (FRENCH)
3	1AA2CBF0019	CABINET BACK SIDE (2)		1JC6P1P0230	QUICK 'N EASY SETUP SHEET
4	1AA0CBF0005-A	ASSY, CABINET BACK CENTER		1AV0U10B43101	ASSY, REMOCON
5	1AA2PAM0146A-	PANEL		1AA2RCM0295-A	RC-BATTERY LID
6	1AA2BUM0431	UNITED BUTTON		★ 1AV4W11B17100	CORD, POWER-3.0MK
7	1AA2DES0784-H	DEC SHEET, AC			,
8	1AA2DES0874	DEC SHEET, AV			
9	1AA2DES0784-G	DEC SHEET, TUNER			
10	1AA2DES0789-G	DEC SHEET DTV			
11	1AA2SDA0008-F	STAND (2)			
12	1AA2DEM0371	DEC RC LED			
13	1AA2DES0861	DEC SHEET, DTV			
14	1AV2BAAS015A-	BADGE, SANYO			
15	1AA2DES0712-F	DEC SHEET, VIZON			

COMPONENT AND TESTPOINT LOCATIONS

MAIN BOARD PARTS SIDE







COMPONENT AND TESTPOINT LOCATIONS (Cont.)


CONTROL BOARD PARTS SIDE

CONTROL BOARD FOIL SIDE







KEY BOARD PARTS SIDE




KEY BOARD FOIL SIDE




FILTER BOARD PARTS SIDE




FILTER BOARD FOIL SIDE



BLOCK DIAGRAM POWER LINES




BLOCK DIAGRAM SIGNAL LINES




IC BLOCK DIAGRAMS

Audio Processor (IC3401)




IC BLOCK DIAGRAMS (Cont.)

Audio AMP (IC001)




IC1201, IC1251 Video and Audio Select




TROUBLESHOOTING FLOW CHARTS

NO POWER




NO AUDIO



TROUBLESHOOTING FLOW CHARTS (Cont.)

NO VIDEO



CONTROL PORT FUNCTIONS

System Control (CPU : IC801)

Pin	Name	Function	I/O	Description	
1	CVin	Reserve	IN	GND (0Vdc)	
2	P70/INT0/TOLCP	LINE OFF	IN	Detect AC Voltage Reduction (Normal: High)	
3	P71/INT1/TOHCP	Reserve	OUT	(Open)	
4	P72/INT2/TOIN	Reserve	OUT	(Open)	
5	P73/INT3/TOIN	RC in	IN	RC Input	
6	AN0	Key in	IN	Key Input	
7	AN1	AFT S-Figure in	IN	AFT S-Figure Input	
8	P82/AN2	Reserve	OUT	(Open)	
9	P83	Reserve	OUT	(Open)	
10	P84/AN4	Panel Size Option	IN	32V: High, 26V: Low	
11	P85/AN5	Reserve	IN	(Open)	
12	P86/AN6	Reserve	IN	(Open)	
13	P87/AN7	SIN	IN	S-Detect	
14	P30/SO6	TV Relay out	OUT	POWER ON/OFF SW (Power On: High)	
15	SB6	IIC-BUS for NV	I/O	(DATA) Active 'L' for IIC data NV	
16	SCK6	IIC-BUS for NV	OUT	(CLOCK) Active 'L' for IIC clock NV	
17	SB6	IIC-BUS for TV	I/O	(DATA) Active 'L' for IIC data TV	
18	SCK6	IIC-BUS for TV	OUT	(CLOCK) Active 'L' for IIC clock TV	
19	DBGP0	DBGP0	I/O	Terminal for De-Bug 1	
20	DBGP1	DBGP1	I/O	Terminal for De-Bug 2	
21	DBGP2	DBGP2	IN	Terminal for De-Bug 3	
22	PC0	ENA/DATA1	I/O	Writing on board (ENA/DATA1)	
23	PC1	DATA0	I/O	Writing on board (DATA0)	
24	PC2	CLK	IN	Writing on board (CLK)	
25	PC3	TB in	IN	Detection for Video Signal (Time base: H)	
26	PC4	Reserve	OUT	(Open)	
27	P00	WDT out	OUT	Watch dog timer (Reserved: Open)	
28	P01	AV SW1	OUT	Selection for AV Selector 1	
29	P02	AV SW2	OUT	Selection for AV Selector 2	
30	P03	AV SW3	OUT	Selection for AV Selector 3	
31	P04	Reserve	OUT	(Open)	
32	P05	Power Fail-1 in	IN	TV Power Error (Error: Low)	
_33	P06	STATUS in	IN	For factory use	
34	P07	Ack out	OUT	For factory use	
35	P20/SO1	Reserve	OUT	(Open)	
36	P21/S11/SB1	Power Fail-2 in	IN	LVDS Power Error (Error: Low)	
_ 37	P22/SCK1	A-OUT Mute	OUT	Audio Out Mute (On: High)	
_38	P23	Audio MUTE	OUT	Audio Mute (On: High)	
39	UTX	UART OUT	OUT	Digital Module microcomputer piece confidence	
40	URX	UART IN	IN	Digital Module microcomputer piece confidence	
41	P26/OSDCK1	THEM DET	OUT	(Open)	
42	BL2	LED ON	OUT	(Open)	
43	VSS2	Vss	IN	GND (0Vdc)	
44	VDD2	Power IN	IN	5V (5Vdc±10%)	
45	P10/S00	Reserve	OUT	(Open)	
46	P11/SI0/SB0	Reserve	OUT	(Open)	

CONTROL PORT FUNCTIONS (Cont.)

System Control (CPU : IC801 Cont.)

Pin	Name	Function	1/0	Description	
47	P12/SCK0	CRT/FPD	IN	Option Setting (CRT: High, FPD: Low)	
48	P13	PDP/LCD	IN	Option Setting (PDP: High, LCD: Low)	
49	PWMA	Reserve	OUT	(Open)	
50	PWMB	Reserve	OUT	(Open)	
51	PWMC	Reserve	OUT	(Open)	
52	P17/PWMD	Reserve	OUT	(Open)	
53	BL1	Reserve	OUT	(Open)	
54	В	Reserve	OUT	(Open)	
55	G	Reserve	OUT	(Open)	
_56	R	Reserve	OUT	(Open)	
_57	HSB	Hsync	IN	GND (0Vdc)	
58	VSB	Vsync	IN	GND (0Vdc)	
59	VSS1	Vss	IN	GND (0Vdc)	
60	XT1	Xin	IN	Main Clock IN/OUT Fosc=8MHz	
61	XT2	Xout	OUT	(Should be connected between IN/OUT pins.)	
62	VDD1	Power IN	IN	5V (5Vdc±10%)	
63	RESB	RESET in	IN	Reset terminal	
64	FILT	FILT out	OUT	PLL Filter	

Mode Switching Table

Mode	AVSW1 (pin28)	AVSW2 (pin29)	AVSW3 (pin30)
Analog Tuner	Low	High	Low
AV1(CVBS)	High	High	Low
AV1(S)	High	Low	Low
AV2(Component 2)	Low	Low	High
AV3(Component 3)	Low	Low	Low
Digital Tuner or HDMI	Low	Low	Low
HDMI (DVI)	Low	Low	Low

SCHEMATIC DIAGRAMS

NOTES ON SCHEMATIC DIAGRAMS

- 1. All resistance values in ohms K=1,000 M=1,000,000.
- 2. Resistors specified with resistance value are "1/6DJ."
- 3. Resistors specified with type of resistor, tolerence and resistance value are "1/4."
- 4. Unless otherwise noted on schematic, all capacitor values less than 1 are expressed in μ F (Micro Farad), and the values more than 1 are in pF.
- 5. All capacitors are 50 WV rating unless oterhwise noted.
- 6. Unless otherwise noted on schematic, voltage reading taken with VOM from point indicated to chassis ground. Voltage reading taken using color-bar signal VHF channel 5, all controls at normal. Line voltage at 120 volts. Some voltages may vary with signal strength.
- 7. Waveforms were taken with color-bar signal and controls set for normal picture. Waveforms marked with an * may vary with signal strength.
- 8. The Symbol indicates a fusible resistor, which protects the circuit from possible short circuits.
- 9. Parts enclosed with are related with X-radiation.
- 10. Isolation border line. Cold Side Hot Side
- 11. Schematic part location numbers may not always match the schematic symbols.

The schematic symbols and part descriptions are correct and should be used.

The part descriptions will be listed under the location number in the parts list.

ELECTROSTATICALLY SENSATIVE DEVICES

Many solid-state devices (especially Integrated Circuits) are Electrostatically Sensitive, and, therefore, require special handling techniques as described under "Servicing Electrostatically Sensitive Devices," on page two in this service literature.


SERVICE NOTES:

- 1. When replacing parts on circuit boards, clamp the lead wires to terminals before soldering.
- 2. When replacing high wattage resistors on circuit board, keep the resistor body 10 mm (3/8) from circuit board.
- 3. Keep wires away from high voltage and high temperature components.

PRODUCT SAFETY NOTICE


THE COMPONENTS DESIGNATED BY A STAR (*) ON THIS SCHEMATIC DIAGRAM DESIGNATE COMPONENTS WHOSE VALUES ARE OF SPECIAL SIGNIFICANCE TO PRODUCT SAFETY. SHOULD ANY COMPONENT DESIGNATED BY A STAR NEED TO BE REPLACED, USE ONLY THE PART DESIGNATED IN THE PARTS LIST. DO NOT DEVIATE FROM THE RESISTANCE, WATTAGE AND VOLTAGE RATINGS SHOWN.

IC, DIODE, AND TRANSISTOR PIN LAYOUTS




CAPACITOR AND RESISTOR CODE CHART

CAPACITOR (Example)




RESISTOR (Example)



For parts or service contact

Sanyo Manfacturing Corporation P.O. Box 2000 3333 Sanyo Road Forrest City, Arkansas 72335-2000

April 2006 SMC



— 38 —

